



vessel. The pigment should be added to the base and should be stirred for 30 seconds till proper dispersion of pigment paste in base. Then add the hardener content to the base until an even color and texture is obtained. And continue the mixing for about 3 to 4 minutes slowly until a completely homogeneous mix is obtained.

**Application:**

The material once mixed should be used within its specified pot life; the material is poured on to the primed surface and spread it to the required thickness with a notched steel trowel, care should be taken not to over work the resin, spreading evenly. After spreading, immediately the floor should be firmly rolled with a spiked nylon roller to help release any entrapped air in the material and help level any slight roll marks. The rolling should be carried out using a "back and forth" technique along the same path. An overlap of 50% with adjacent paths is recommended.

**Coverage:** 3 M<sup>2</sup> @ 1mm thick for a pack of 5 Kgs

**Supply:** 5kg pack

MYK SCHOMBURG INDIA PVT LTD  
(An Indo-German JV)  
8-2-703/A, 3<sup>rd</sup> Floor, Leela Gopal Towers,  
Road No. 12, Banjara Hills,  
Hyderabad -500 034  
Tel: +91 40 3040 0000  
Email: mykschomburg.com  
www.mykschomburg.com